



## PLSS Section Corner ID System

A unique id is given to each corner in a PLSS section; always start at the Southeast corner of the section. The number is based on the following 5 elements:

1. Township Number, i.e. T35N = 35
2. Range Number, i.e. R11E = 11
3. Section Number, i.e. 25 = 25
4. North from Southeast corner of section, i.e. first 1/16 corner north = 10
5. West from Southeast corner of section, i.e. first 1/16 corner east = 10

Note: Increase by 10 for every forty corner thereafter. MC's are prorated between forty corners.

